

# Dummy Piece instruction

Fold here and fit on the door edge

Backset 2 3/8" (60mm)

Backset 2 3/4" (70mm)

41

2-Ø7

**dummy piece lock photos**

SCREW  
washer  
rose  
handle

- prepare the installation lock tool
- according to the position of the door opening direction and the use of lock in th position of the door drilling the image same size
- As shown below, respectively, remove the dummy locked screws, washers.
- installed locks on the steps and methods

Tools needed	
<p>drill bit 17/64" (7mm)</p>	<p>power drill</p>
<p>screwdriver</p>	<p>Pencil</p>

**install lock step and methods**

**1 accord to the paper guide line**

- According to the structure of door Confirm the door Apothem And make notes with a pencil according to the specification of the size of the subject on the door to be drilled at the correct position

the side door  
the front door

**2 hole making**

- Use the Hand drill in front of the door marked place drill Ø7mm installation hole.

**3 lock installation**

- fitment the dummy lock bolt screw in the drill hole place

**4 tight screw**

- put the washer into the screw and fitment with the bolt, tight with screwdriver

# Dummy Piece instruction

Fold here and fit on the door edge

Backset 2 3/8" (60mm)

Backset 2 3/4" (70mm)

41

2-Ø7

**dummy piece lock photos**

SCREW  
washer  
rose  
handle

- prepare the installation lock tool
- according to the position of the door opening direction and the use of lock in th position of the door drilling the image same size
- As shown below, respectively, remove the dummy locked screws, washers.
- installed locks on the steps and methods

Tools needed	
<p>drill bit 17/64" (7mm)</p>	<p>power drill</p>
<p>screwdriver</p>	<p>Pencil</p>

**install lock step and methods**

**1 accord to the paper guide line**

- According to the structure of door Confirm the door Apothem And make notes with a pencil according to the specification of the size of the subject on the door to be drilled at the correct position

the side door  
the front door

**2 hole making**

- Use the Hand drill in front of the door marked place drill Ø7mm installation hole.

**3 lock installation**

- fitment the dummy lock bolt screw in the drill hole place

**4 tight screw**

- put the washer into the screw and fitment with the bolt, tight with screwdriver