



## **Latch Lock Fitting Instructions**

- A – Choose the height of the lock, we suggest 900mm from the bottom of the door to the centre of the euro hole
- B – Using the template supplied mark the face plate centrally on the door edge
- C – Select a drill bit to the required opening
- D – Drill overlapping holes down the centre line slightly deeper than the lock body
- E – Clean out any excess wood with a chisel
- F – Place the lock into the opening and adjust if necessary
- G – With the lock in position mark around the face plate
- H – Chisel out the marked area
- I – Drill hole for spindle
- J – Drill holes for euro cylinder
- K – Fit the striker to the jamb

Please note this is a guideline only on fitting this lock and we recommend a qualified installer install the lock.